

SANELA



TOILET FLUSH



Installation
& maintenance
instructions.

General Information

- Designed for indoor use only. Do not expose to elements of nature.
- All plumbing and electrical connection must be made in accordance with AS/NZ3500 and installation with AS/NZ3500.2.

Warnings

- Read all instructions before attempting to install this system. It is recommended a qualified & registered plumber completes the install.
- Ensure pipe work is thoroughly flushed before installing the flush control (internal solenoid). Solenoid components are susceptible to debris and require additional flushing compared to a standard plumbing fixture.
- Consideration should be given to any regulations relating to an air gap, an air break or double check valve to protect against back flow.

Operating Instructions and Parts Manual

Please read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage. Retain instructions for future reference.

Sanela Toilet Flush Control

Sensor operated flush control for single toilet. Non touch infrared system detects and responds to movement and flushes only after user has left active range. High quality electronics combined with elegant aesthetics.


Specifications

Power Supply	Mains - 230V AC, 50Hz (input) - 24V DC (output)
Location	Wall mounted above the toilet
Control	Infra-red sensor
Stainless Steel Cover	170 x 170 x 10mm
Mounting Box	145 x 155 x 100mm
Operating Voltage	24V DC, 7W
Active Range	0.6- 0.75m - system reacts to user attendance in active range (0.7m) for min stay time of 7.5 - 7.75secs
Flush Cycles	Short Flush: (2s) min stay 7.75 secs, max 45secs Long Flush: (5s) min stay 45 secs (adjustable 0.5 - 15.5 secs) Manual Push Flush: (cleaning) Hygiene Flush: 24hrs after last use
Recommended Pressure	0.15 - 0.6 Mpa (1.5-6 Bar)
Rate of Flow	70 L/min @ 0.15MPa (inf. Data)
Water Inlet	Ø min 32mm (PN 16) male thread G 1"
Water Outlet	Male thread G 1"
Warranty	24 months
Product Code	STI01AC

Planning


- Ensure an appropriate piping design (sizing etc). This will eliminate issues arising from flow, pressure and water hammering.
- Where appropriate install necessary filters, water hammering arrestors and water pressure reducing valves (recommended pressure 1 to 6 bar). This will minimise future maintenance.
- Install isolation valve to enable ease of future maintenance.

Components



1	Stainless steel cover
2	Mounting box cover
3	Screw (x2)
4	Screw (x4)
5	Allen key
6	Mounting box

Standard Functions



1. Person stays within active range for min stay of 7.5secs

2. Water flows after person leaves active range
FACTORY SETTINGS 5 s.


3. Hygiene flush automatically every 24 hours
AUTOMATIC

4. Optional manual flush operation
MANUAL FLUSHING

5. Operating pressure range

External Power Supply Installation

Input	230V / 50 Hz
Output	24 V DC
IP rating	IP 55
Operating temperature	5°C - 40°C
Rated power	10W




Important

To be installed in accordance with all NZ electrical regulations. It must be carried out by a qualified professional.


Positioning of the mounting box should be 500mm from the floor and consider:

1. Moisture ingress due to plumbing fault
2. Ongoing maintenance and accessibility


The mounting box can be surface mounted or within the service or ceiling cavity.




1 Ensure mains power supply is off




2 Mark mounting point(s) on surface




3 Drill and insert appropriate wall anchors if required




4 Remove cover from mounting box



5 Fix mounting box to wall




6 Pass mains (230V) power supply into mounting box via grommet and terminate accordingly




7 Reinstall cover of mounting box and ensure sealed. Tighten grommet to ensure snug around cables

Note: Power supply should be secured via current breaker before the external supply (not included)


Installation




Ensure mains power supply is off. Align piping arrangement with water inlet/outlet.




Make certain a power supply connection has been allowed for and the correct transformer has been supplied.




Insert mounting box in place. Ensure pipework has been flushed thoroughly.




Pass power supply from transformer into mounting box via grommet. Connect pipework securely.




5 Screw temporary cover in place (if applicable).




6 Reinststate mounting surface (if applicable).




7 Remove temporary cover (if applicable).




8 Using the allen key, remove 2 x security screws from the bottom of stainless steel cover and separate cover from plate.




9 Fix plate to mounting box (4 x screws).





10 Connect electronics to solenoid valve.




Connect power supply to electronics, via wago connectors. Note polarity.



Refit stainless steel cover by carefully inserting top mounting points first, followed by tightening of 2 x security screws at the bottom - use allen key.



Turn power supply on. It is necessary, for the proper function, to keep the unit under constant voltage (don't connect the power supply unit behind the switch into the light circuit)



Once power on, avoid coming within active range for 10 seconds while sensor calibrates.


Important

Pipework is required to be flushed thoroughly prior to installation. Foreign debris may reduce level of flow and in some cases damage the solenoid valve.

- The sensor of the unit must not be obstructed.
- Avoid positioning reflective objects or surfaces in front of the sensor. This can cause false activation.
- All plumbing and electrical installation must be carried out by a qualified person and in accordance with applicable codes and regulations.

Note:

If you require to modify any of the factory settings please request the Sanela remote SLD03.



Maintenance

- It is recommended that the solenoid valve and all filters be inspected for foreign debris and cleaned annually (more frequently if necessary)
- Clean cover regularly using soapy water and a soft cloth or wet sponge
- DO NOT clean cover with any abrasive material or chlorine/acid based cleaning product. This may damage the filter of the infrared sensor and/or the finish.

Troubleshooting

Symptom	Possible Cause	Corrective Action
No water flow - sensor blinked when within active range	<ul style="list-style-type: none"> a. Water supply b. Water connections c. Filter is clogged d. Faulty solenoid 	<ul style="list-style-type: none"> a. Ensure water at source b. Ensure connections c. Clean filter (any valve and solenoid) d. Replace solenoid
No water flow - sensor did not blink when within active range	<ul style="list-style-type: none"> a. Power supply b. Power connections to wago connectors c. IR sensor damaged or faulty 	<ul style="list-style-type: none"> a. Ensure power at source b. Check all connections and polarity c. Replace IR sensor
Water doesn't stop flowing	<ul style="list-style-type: none"> a. Dirty IR sensor b. Obstruction in detection zone c. Water drop on sensor eye d. Ghost sensing due to reflection e. Debris in solenoid 	<ul style="list-style-type: none"> a. Clean IR sensor b. Remove obstruction c. Wipe sensor d. Remove reflective surface or reposition e. Clean and/or replace solenoid
Reduced flow rate	<ul style="list-style-type: none"> a. Filter clogged b. Water supply 	<ul style="list-style-type: none"> a. Clean filter b. Check pressure / flow at source

Supreme Comprehensive Warranty

Your Sanela Toilet Flush is fully guaranteed against defective materials and faulty workmanship commencing from the date of sale (according to SPL's records), subject to it being installed and maintained in accordance with the manufacturer's instructions.

SPL (2021) Limited warrants that should any part of the flush control fail within the given warranty period (24 months), it will be remedied by SPL. The flush control should be returned to SPL (2021) Limited for all warranty claims. The cost of cartage will be payable by the customer.

This warranty excludes:

- Incorrect installation, or installation that does not specifically follow the installation guidelines supplied
- Failure to follow manufacturer's maintenance instructions
- Damage/Failure resulting from:
 - the use of non-authorized parts
 - authorised parts not installed in accordance with the manufacturer's instructions
 - accidental damage, negligent use, misuse, vandalism, neglect
 - damage caused either directly or indirectly by external sources (incorrect power supply, natural disaster, or insect infestation)

• Water ingress caused by property maintenance or flooding

• Negligent cleaning practices (water ingress, harmful chemical etc)

The above includes consequential damage to any other goods, furnishings, or property.

- Normal wear and tear and consumable parts (batteries etc)
- This warranty does not displace any statutory warranty in relation to the unit but any liability of SPL (2021) Limited under any statutory warranty will be limited to a replacement or repair of the unit or payment of the cost of such replacement or repair at the sole discretion of SPL (2021) Limited

Note:

- Warranty only extends to products purchased and installed in New Zealand.
- Contamination or poor water quality is not covered by product warranty.
- Damage to solenoid caused by inadequate flushing or excess water pressure is not covered by the product warranty.

SPL Limited
PO Box 437, Cambridge 3450
New Zealand

p. +64 7 823 5790
e. office@splwashrooms.co.nz